UNLOCK THE POWER OF PROEDGE

STEP 1

When logging into StorID, verify that Bluetooth and location tracking are enabled on your phone. Wake the lock by pressing the button the ProEdge.

STEP 2

When the lock is awake, it will appear in the list of active devices on StorID. A window will appear asking "Which unit do you want to unlock?"

STEP 3

Click on the lock you wish to open. A window will appear asking "Do you want to unlock Lock?"

STEP 4

Swipe right on the window to unlock. A "Lock opened" message will appear. A green LED light will display on the ProEdge.







DOWNLOAD **STURID** TODAY

APPLE



ANDROID

